

## EASY 3

Modello Model Modèle Modelo	Modello forno Oven model Modèle four Modelo horno	D cm	A cm	B cm	C cm	L cm
<b>EASY 3</b>	<b>cm</b>	<b>cm</b>	<b>cm</b>	<b>cm</b>	<b>cm</b>	<b>cm</b>

### MSR - MSP

<b>EASY 80</b>	<b>MSR: 40810 - 50810 - 60810</b>	105	144	209	353	130
	<b>MSR: 40812 - 50812 - 60812</b>	125	164	229	393	
	<b>MSR: 40814 - 50814 - 60814</b>	145	184	249	433	
	<b>MSR: 40816 - 50416 - 60816</b>	165	204	269	473	
	<b>MSR: 40818 - 50818 - 60818</b>	185	224	289	513	
	<b>MSR: 40820 - 50820</b>	205	244	309	553	
<b>EASY 100</b>	<b>MSR: 41010 - 51010</b>	105	144	209	353	150
	<b>MSR: 41012 - 51012</b>	125	164	229	393	
	<b>MSR: 41014 - 51014</b>	145	184	249	433	
	<b>MSR: 41016 - 51016</b>	165	204	269	473	

